



Step #1

Mount your CMI Shim in-between the Spa Skirting and the CMI Bracket using the supplied #10 x 1-1/2" screws.

ITEM	PART#	DESCRIPTION	QTY
A	101095	CMI BRACKET SHIM	2
B	100909	#10 X 1-1/2" PHILIPS PAN HEAD SCREW	24