



Step #1

Position the spa cover (in closed position) on the spa, making sure that all four corners are properly positioned and square on the spa. After determining the appropriate corners that the mounting brackets will be attached to, remove the spa skirt plastic corners by unscrewing the black thumb screws.

Step #2

By positioning the mounting brackets 8" down from the top of the spa shell, approximately 9" of clearance behind the spa will be needed. With the skirt corners removed, use the #10 X 1" Screws to attach the left and right mounting brackets to the appropriate sides of the plastic section of the spa. Use the #10 X 1-1/2 self-tapping screws to attach the mounting brackets to the metal section of the corners of the spa (See Fig. 1). **Note: It is easier to attach the pivot arms to the mounting brackets prior to attaching the mounting brackets to the spa (See Fig. 2).**

Step #3

Insert the long end of the support arms into the center coupler, then slide the support arms into the pivot arms (See Fig. 3).

Step #4

Lay the Covermate on the spa cover. Adjust the center coupler and support arms so that the center coupler is lying parallel to the spa cover's hinge about 1/2" away (See Fig. 4). Using the #10 X 5/8" self-tapping screws, fasten the support arms to the pivot arms and the center coupler. **Note: Be sure to rotate the center coupler so that the inserted screws are at a horizontal angle with the heads facing the back of the spa.**

Step #6

Slip the black hand grips to the edge of the spa cover and snap the small black dome caps on the heads of all exposed #10 screw heads.

Step #7

Attach the provided 3 hook TowelMate on the preferred side of your Covermate by simply snapping it into place and inserting the middle self-tapping screw (See Fig. 5).

CAUTION!

Do not use the Covermate in high wind condition. Injury from the spa cover being blown over and impacting the spa user can occur.

ITEM	PART#	DESCRIPTION	QTY
A	100001	SUPPORT ARM	2
B	100002	FOAM GRIP	2
C	100003	CENTER COUPLER	1
D	100004	PIVOT ARM	2
E	100007	PIVOT ARM CAP	2
F	100344	BUSHING	4
G	100555	MOUNTING BRACKET-LEFT	1
H	100556	MOUNTING BRACKET-RIGHT	1
I	100008	TOWELMATE	1
J	100010	3/8 X 3" HEX CAP BOLT	2
K	100011	3/8 NYLON LOCKNUT	2
L	100012	3/8 FLAT WASHER	4
M	100013	#10 X 5/8" SELF-TAPPING SCREWS	12
N	100014	#10 X 1" MOUNTING SCREWS	16
O	100913	#10 X 1-1/2" SELF-TAPPING SCREWS	14
P	100015	LARGE BLACK DOME CAP	2
Q	100016	SMALL BLACK DOME CAP	42