
SNAR BEISURE Concepts



Installation Instructions - Updated as of 07/31/19

Step #1

Position the Smartop (in closed position) on the spa making sure that all four corners are properly positioned and square on the spa.

Step #2

Attach the EAS handle to the EAS bracket using the supplied $5/16 \ge 1-1/4$ " button head socket bolt *(see Fig. 1).*

Step #3

Attach the Vanish XL pivot arms to the Smartop using the supplied button head socket bolts and let the assembly hang freely (see Fig. 2). Note: Make sure to run the bolts from the inside out. The locknuts need to be facing outwards. Also, make sure to use the supplied plastic washers as a spacer in between the metal plate on the pivot arms and the Vanish XL cover mounting bracket. Do not overtighted bolts, the pivot arms must rotate freely.

Step #4

Swing the Vanish XL bracket assembly forward making sure the two pivot arms rest against each other (see Fig. 2). Attach the Vanish XL bracket assembly to the spa cabinet using the supplied $\#10 \times 1-1/2$ " mounting screws. Note: Make sure to put downward pressure on the Smartop when attaching the Vanish XL bracket assembly to the spa cabinet to ensure the Smartop is making a good seal with the acrylic of the spa.

Step #5

Repeat steps 2, 3 & 4 for the opposite side of the spa.

Step #6


To attach the shocks to the bracket assembly, partially open your Smartop cover and snap the shocks onto the appropriate ball studs (*see Fig. 3*). *Note: Make sure the black body of the shock is pointing towards the middle of the Smartop.*

Step #7

Open the Smartop so it is in the fully upright position. Using the supplied #10 x 1-1/2" mounting screws, finish attaching the Vanish XL bracket assembly to the spa.


Step #8

Attach the Vanish XL cover plate to the bracket assembly using the supplied self-tapping screws. Next, thread the 3/8 x 3/4" hex cap bolt through the hole in the cover plate that lines up with the rear pivot arm (*see Fig. 4*). *Note: Do not overtighten hex cap bolt.*



Step #9

Attach the side tub lock cable assembly to the pre-installed tub lock bracket on the side of the aluminum trim on the Smartop and turn the knob to lock it in place. Next, apply downward pressure on the Smartop and mark where the tub lock assembly needs to be attached to the spa cabinet. Unlock and remove the side tub lock cable assembly from the tub lock bracket on the Smartop. Attach the tub lock assembly triangle plate to the spa cabinet using the supplied #8 x 3/4" philips flat head screws (black). *Note: Do not overtighten the screws when attaching to the spa cabinet.* Swing the tub lock assembly cable up and re-attach to the tub lock assembly bracket on the Smartop and lock it in place. *Note: Do not cover the service panel with the side tub lock assembly (see Fig. 4 & 5 for a complete look).*



Step #10

If the thermal seal on the underside of the Smartop does not completely seal around the control panel of your spa, an additional thermal seal control pad has been included with the Smartop. Close the Smartop and determine the position of the thermal seal pad. Open the Smartop cover onto itself, dry thoroughly and remove the backing of the thermal seal pad and attach it to the underside of the Smartop in the desired position (*see Fig. 6*).

Operation of your Smartop Cover

1) Fold the first half of the Smartop cover off the spa. While gripping the EAS handle, motion the Smartop cover into it's vertical upright position.

ITEM	PART#	DESCRIPTION	QTY
A(L)	101733	ST VANISH XL BASE BRACKET (L)	1
A(R)	101734	ST VANISH XL BASE BRACKET (R)	1
B(L)	101735	ST VANISH XL COVER MOUNTING BRACKET (L)	1
B(R)	101736	ST VANISH XL COVER MOUNTING BRACKET (R)	1
C	101737	VANISH XL PIVOT ARM - FRONT	1
D	101738	VANISH XL PIVOT ARM - REAR	1
E	101739	VANISH XL PIVOT ARM PLATE - FRONT	1
F	101740	VANISH XL PIVOT ARM PLATE - REAR	1
G(L)	101741	BALL STUD MOUNTING PLATE - LEFT	1
G(R)	101742	BALL STUD MOUNTING PLATE - RIGHT	1
H(L)	101743	ST VANISH XL COVER PLATE (L)	1
H(R)	101744	ST VANISH XL COVER PLATE (R)	1
	101745	VANISH XL COVER PLATE ANCHOR	2
J	101746	LARGE PIVOT ARM SHIM	4
K	101747	SMALL PIVOT ARM SHIM	4
L	100244	5/16 BALL STUD	12
М	100032	5/16 NYLON LOCKNUT	12
N	101749	3/8 X 2" BUTTON HEAD SOCKET BOLT - BLACK ZINC	4
0	100012	3/8 FLAT WASHER	4
Р	100011	3/8 NYLON LOCKNUT	4
Q	101750	3/8 PLASTIC SHIM WASHER	4
R	101752	3/8 X 3/4" HEX BOLT - BLACK ZINC	2
S	101596	EAS HANDLE	2
Т	101752	5/16 X 1-1/4" BUTTON HEAD SOCKET SCREW - BLACK ZINC	2
U	100909	#10 X 1-/2" PHILIPS PAN HEAD MOUNTING SCREW	68
V	100836	#10 X 1" PHILIPS PAN HEAD SELF-TAPPING SCREW - AL2000 BLACK	12
W	100015	LARGE BLACK DOME CAP	6
Х	101510	SHOCK - 335N	2
Y	101390	SHOCK - 800N	2
Z	101056	SIDE TUB LOCK ASSEMBLY	4
AA	101065	#8 X 3/4" PHILIPS FLAT HEAD SCREW - BLACK ZINC	12
AC	101079	THERMAL SEAL CONTROL PAD	1
AD	101078	LOCK	1
AE	101762	RUBBER BUMPER	2
AF	101650	#8 X 1-1/4" PHILIP FLAT HEAD SELF-DRILLING SCREW - BLACK ZINC	2

CAUTION!

Do not use the Smartop in high wind conditions. Injury from the spa cover being blown over and impacting the spa user can occur.

For additional information on our Smartop product, please visit our website: "www.smartopspacover.com"