



### Step #1

Slip the upper mounting bracket on the rail. Next, slide the lower mounting bracket on the rail (see Fig. 1).

### Step #2

Attach the upper mounting bracket to the spa cabinet directly under the acrylic of the spa with the supplied #12 x 1" mounting screws (see Fig. 1).

### Step #3

Slide the rail up/down to determine the desired height. Next, attach the lower mounting bracket to the spa cabinet with the supplied #12 x 1" mounting screws (see Fig. 1). **Note: The rail should be mounted so that it clears the top of the spa acrylic by a minimum of 1".**

ITEM	PART#	DESCRIPTION	QTY
A	100294	SAFE-T-RAIL	1
B	100295	UPPER MOUNTING BRACKET	1
C	100291	LOWER MOUNTING BRACKET	1
D	100801	#12 X 1" MOUNTING SCREWS	16