

Step #1

Start by laying one of the risers on a flat surface. Insert the tread into the slots on the riser and loosely secure with the supplied #1/4 x 3/4" flat head machine screws, washers and locknuts (See Fig. 1).

Step #2

Insert the "U" shaped support channels into the same slot in the riser. **Note: Make sure the foam on each end of the support channel faces the tread.** Secure the "U" shaped support channels to the riser using the supplied #10 x 3/4" self-drilling screws (see Fig. 2).

Step #3

Attach the other riser onto the tread and support channels. Refer to step #1 and step #2 to loosely secure (see Fig. 3).

Step #4

Attach the rear brace to the back of the step and secure using the supplied 1/4 x 3/4" flat head screws, washers and locknuts (see Fig. 4).

Step #5

Go back through and make sure sure to tighten all of the flat head machine screws from step #1 & step #3.

Step #6

Attach the ModStep 3 assembly to the ModStep 2 using the (6) 1/4 x 3/4" flat head screws, (6) 1/4 washers and the (6) 1/4 nylon locknuts (see Fig. 5).

