

Step #1

Start by laying one of the risers on a flat surface. Insert both treads into the slots on the risers and loosely secure with the supplied #1/4 x 3/4" flat head machine screws, washers and locknuts (See Fig. 1).

Step #2

Insert the "U" shaped support channels into the same slots in the risers. *Note: Install 3 support channels under the double tread and one support channel under the single tread. Make sure the foam on each end of the support channel faces the tread.* Secure the "U" shaped support channels to the riser using the supplied #10 x 3/4" self-drilling screws (see Fig. 2).

Step #3

Attach the other riser onto the treads and support channels. Refer to step #1 and step #2 to loosely secure (see Fig. 3).

Step #4



Attach the rear brace to the back of the step and secure using the supplied 1/4 x 3/4" flat head screws, washers and locknuts (see Fig. 4).

Step #5

Go back through and make sure sure to tighten all of the flat head machine screws from step #1 & step #3. *Note: Make sure the single tread is slid as far forward into the slot as possible before tightening the screws.*

Step #6

Attach the ModStep 4 assembly to the ModStep 2 using the (6) 1/4 x 3/4" flat head screws, (6) 1/4 washers and the (6) 1/4 nylon locknuts (see Fig. 5).



ITEM	PART#	DESCRIPTION	QTY
A	102364	MODSTEP 4 RISER - LEFT	1
B	102365	MODSTEP 4 RISER - RIGHT	1
C	102351	MODSTEP REAR CROSS BRACE	2
D	102349	MODSTEP SINGLE TREAD	1
E	102350	MODSTEP DOUBLE TREAD	1
F	102368	MODSTEP U SUPPORT CHANNEL	4
G	101396	1/4 x 3/4" FLAT HEAD MACHINE SCREW - STAINLESS STEEL	16
H	100608	1/4 FLAT WASHER	16
I	100607	1/4 NYLON LOCKNUT	16
J	101414	#10 X 3/4" SELF TAPPING SCREW - STAINLESS	8

